# PCIe 5G 5-Speed Multi-Gigabit Network Adapter

User Manual Ver. 1.00

All brand names and trademarks are properties of their respective owners.

# **Contents:**

Chapter 1: Introduction	3
1.1 Product Introduction	3
1.2 Features	3
1.3 Systems Requirements	4
1.5 Package Contents	4
Chapter 2: Getting Started	5
2.1 Hardware Layout	5
2.2 Hardware Installation	6
2.3 Driver Installation	6
2.3.1 Installation for Windows	6
2.4 Verifying the installation	6
2.4.1 Verifying for Windows	6

# **Chapter 1: Introduction**

#### 1.1 Product Introduction

This specification defined a high performance PCIe Ethernet adapter which provides single RJ-45 port for network connection of data rate up to 5Gbps. The PCIe Gen3 x1 interface enables running at maximum full duplex throughput as well as backward compatible with Gen1/2 PCIe slots. With this adapter, the network environment permits easy upgrade to 5Gbps network bandwidth over existing Cat 5E network cabling.

#### 1.2 Features

- PCIe Gen3 x1 form factor
- Supports standard and low profile systems
- Supports 5-speed 5G/2.5G/1G/100M/10Mbps auto negotiation
- Runs 5Gbps on Cat 5E cable up to 100m
- Supports Wake-On-LAN (WoL)
- Up to 16KB jumbo frame
- Checksum and TSO offload

Network ARP and NS offload

## 1.3 Systems Requirements

Operating systems supported are (both 32 and 64 bits)

- Windows 11/10
- Linux kernel 3.10 or later

## 1.4 Product Diagram




## 1.5 Package Contents

- 1 x PCIe 5G 5-Speed Multi-Gigabit Network Card
- 1 x User Manual

# Chapter 2: Getting Started

## 2.1 Hardware Layout

#### 10M/100M/1000M/2.5G Link/Activity Indicator



5G Link/Activity Indicator

#### Link/Activity Indicator:

Link/Activity indicator:		
LED	Description	
Link/Activity LED	Indicates Link Speed: • Solid Green = 10M/100M/1000M/2.5Gbps • Solid Green = 5Gbps	

## 2.2 Hardware Installation

- 1. Turn off the power to your computer.
- 2. Unplug the power cord and remove your computer's cover.
- 3. Remove the slot bracket from an available PCIe slot.
- 4. To install the card, carefully align the card's bus connector with the selected PCIe slot on the motherboard. Push the board down firmly.
- 5. Replace the slot bracket's holding screw to secure the card.
- 6. Secure the computer cover and reconnect the power cord.

#### 2.3 Driver Installation

The following section shows you how to install PCIe 5G 4-Speed Multi-Gigabit Network Card driver on different operating systems.

## 2.3.1 Installation for Windows


- 1. Go to URL http://www.sunrichtech.com.hk/
- 2. Search N-920, download the driver.
- 3. Follow the on-screen instructions to finish installing the driver.

## 2.4 Verifying the installation

## 2.4.1 Verifying for Windows

 Click on the "Device Manager" tab in the Windows Control Panel.

Start > Control Panel > Device Manager



- 2. Expand "Network adapters" item, and you can read "Realtek PCIe 5GbE Family Controller" in the Device Manager.
  - Network adapters
     Realtek PCle 2.5GbE Family Controller
     Realtek PCle 5GbE Family Controller